



ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
102	12318-010A102-1	HAMMER CASE	404	12308-0070001-1	VALVE SPRING			
103	1230K-0070002-1	HAMMER CASE BUSHING	405	12346-0074701-1	EXHAUST DEFLECTOR			
104	1230F-0100001-1	HAMMER CASE PILOT	406A	12309-0074709-1	AIR INLET			
105	1230S-0070002-1	HAMMER CASE GASKET	406B	12309-0074712-1	AIR INLET			
106	2040306-00010-0	SOCKET RETAINER	407	12225-0074701-2	TRIGGER UNIT			
107	2041100-01070-0	O - RING	408	12351-0070001-1	MUFFLER			
108	1230D-0070001-1	ANVIL	409	2041102-02020-0	O - RING			
109	1230B-0070001-1	HAMMER FRAME PIN	411	2041102-02010-0	O - RING			
110	1230C-0070001-1	HAMMER	412	2040304-48010-0	EX-CONCENTRIC RING			
111	1230E-0100001-1	HAMMER FRAME	417	1230K-0070007-1	BUSHING			
112	12340-0104701-1	WASHER						
113	2042400-00010-0	HAMMER CASE GREASE FITTING						
201	12302-0106608-2	HOUSING						
202	1230N-0074701-1	HANDLE GRIP						
203	1230S-0070001-1	HOUSING GASKET						
204	1230L-0070002-1	REVERSE VALVE						
205	2041104-03030-0	O - RING						
206	12223-0074706-1	REAR COVER UNIT						
207	1230M-0074701-1	LEVER						
208	2040800-01010-0	STEEL BALL						
209	1230J-0070002-1	SPRING						
210	2040100-03030-2	BOLT ASSY						
301	2041200-00054-0	BEARING						
302	12312-0100001-1	FRONT BEARING PLATE						
303	12315-0103001-1	CYLINDER						
304	12313-0103001-1	ROTOR						
305	12314-0100001-1	BLADES						
306	12316-0074701-1	REAR BEARING PLATE						
307	1230B-0100001-1	PIN						
308	2041200-00083-0	BEARING						
401	1230K-0070001-1	INSERT BUSHING						
402	12319-0070001-2	SEAL						
403	12226-0074701-1	TIP VALVE						