


STRAIGHT AIR SCREWDRIVER



Index No.	Parts No.	Description	Index No.	Parts No.	Description
1	84201	Housing	29	80229	Drive Dog
2	30102	Spring Pin (3*24L)	30	80230	Retaining Ring (3)
3	51203	Air Inlet	31	80231	Retaining Ring
4	84204	Throttle Lever	32	80232	Cam Spindle
5	84205	Valve Stem	33	40145	Steel Ball (1/8")
6	84206	Valve	34	80234	Clutch Carrier
7	30107	O-Ring (3.8*1.9)	35	80235	Steel Ball (4) (1/4")
8	30108	Spring	36	80236	Washer
9	84209	O-Ring (2*1.5)	37	80237	Spring
10	84210	Reverse Lever	38	80238	Washer
11	80211	Motor Gasket	39	80239	Adjust Nut
12	84212	Reverse Retainer	40	80240	Spacer
13	030113	Ball Bearing (2) (626zz)	41	80241	Clutch Housing
14	80214	End Plate (2)	42	80242	Ball Retainer
15	80215	Rotor	43	80243	Spring
16	80216	Rotor Blade (5)	44	80244	Washer
17	80217	Pin (2) (2.5*10L)	46	84246	Throttle Valve Plug
18	80218	Cylinder	47	51229	Retaining Ring
19	80219	Spacer	48	51206	Exhaust Deflector
20	80220	Spring	49	84249	Screw (2) (M3*15L)
21	80221	Spring Guide	50	40134	O-Ring (7.8*1.9)
22	80222	Internal Gear	51	84251	Spring
23	80223	Planet Gear (3)	52	84252	Reverse Bushing
24	30124	Pin (3) (4*13.8L)	54	84254	Rear Gasket
25	80225	Bushing (3)	55	84255	Rear Cover
26	80226	Work Spindle	56	80202	Spring Pin (2.5*24L)
27	080227	Ball Bearing (6201z)	57	84257	Hook
28	80228	Clamp Nut			

842-0001

9,17,2003