



Part NO	Description
1	Cover
2	Driver
3	Spring
4	Ball
5	Primary Arm
6	Cam
7	Acting block(+)
8	Acting block(-)
9	Conical Spring
10	Ball of Arm
11	Adjustment Screw
12	Dowel Pin
13	O-Ring
14	Screw $\times 2$
15	Defacing Button
16	E-Retaining Ring
17	Neck Pin
18	Lever of Tube
19	Plastic Plug
20	Roller
21	Roller Pin
22	Roller Bracket
23	Ball of Bracket
24	Compression Spring
25	Washer
26	Propulsive Post
27	Guide Pin
28	Adjustment Handle
29	Adjustment Post
30	Adjustment Nut
31	Locking Ring(inner)
32	Locking Ring(outer)
33	Washer
34	Screw
35	Spring
36	Ball